

## How to use wireless schedule?

# It is suitable for : N100RE, N150RH, N150RT, N151RT, N200RE, N210RE, N300RT, N301RT , N300RH, N302R Plus, A702R, A850, A3002RU.

#### **Application introduction:**

This router has a built-in real time clock which can update itself manually or automatically by means of Network Time Protocol (NTP). As a result, you can schedule the router to dialup to the Internet at a specified time, so that users can connect to the Internet only during certain hours.

#### STEP-1:

Please login to the web-configuration Interface of the router

### STEP-2: Check Time Zone Setting

Before using schedule function you have to set your time correctly.

2-1. Click System->Time Zone Setting in the sidebar.



2-2. Enable NTP client update and choose the SNTP server, click Save Changes button for saving changes.

Time Zone Setting	
Current Time	Yr 2018 Mon 9 Day 20 Hr 10 Mn 2 Sec 6
Time Zone Select	Get GMT (GMT+08:00)Beijing, Chongging, Hong Kong, Urumaj
	Enable NTP client update
	Automatically Adjust Daylight Saving
SNTP server	130.149.17.8 - Europe

Apply	

#### **STEP-3: Wireless Schedule Setup**

3-1. Click Wireless->Wireless Schedule



3-2. Enable the schedule at first, in this section, you can setup the specify time so the WiFi will be on during this period.

The picture is a example, and WiFi will be on from eight o' clock to eighteen o'clock on Sunday.

Wireless	Schedule	Enable 🔻 1	
On	Days	From	То
	Sun 🔻	08 ▼ (h) 00 ▼ (m)	18 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 <b>v</b> (h) 00 <b>v</b> (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 ▼ (h) 00 ▼ (m)	00 ▼ (h) 00 ▼ (m)
	Sun 🔻	00 <b>v</b> (h) 00 <b>v</b> (m)	00 ▼ (h) 00 ▼ (m)

#### Wireless Schedule

3 Refresh