

N200RE-V5 Quick Installation Guide

It is suitable for : N200RE-V5

Installation Diagram







Method One: login via tablet/Cellphone

STEP-1:

Activate the WLAN function on your Phone and connect to TOTOLINK_N350RT. Then run any Web browser and enter http://itotolink.net in the address bar.

WLAN		
Turn on or turn off		
WLAN		
WLAN+ Enhanced Internet experience	On >	
Available networks		
TOTOLINK_N350RT	(íŗ	
TOTOLINK_A7100RU	(ŀ·	
TOTOLINK_TestA Encrypted	(1)	
TOTOLINK_TestB	((i:	



Click Quick Setup.

itotolink.net/phone/login.hti



STEP-2 :

Enter admin for the password and then click LOGIN.

Q TOTOLINK		0
		>
2	2	
Administr	rator Login	
P		
LOG	GIN	

STEP-4 :

Time Zone setting. According to your location, please click the Time Zone to choose a correct one from the list, then click Next.



STEP-5 :

Internet Setting. Choose a suitable connection type from the list and fill in the information required, then click Next.

() itotolink.net/phone/wizard.ł ()
Static IP O
Dynamic IP 💿
PPPoE O
PPTP O
L2TP O

STEP-6 :

Wireless Setting. Create passwords for 2.4G and 5G Wi-Fi (Here users could also revise the default Wi-Fi name) and then click Next.

itotolink.net/phone/login.hti				
<				
Ø				
Wireless				
Radio On/Off 2.4GHz:				
Network name(SSID):	TOTOLINK_N200RE			
Password:	······			
Hide SSID:				
Back	Next			
•••				

STEP-7:

For security, please create a new Login Password for your router, then click Next.



STEP-8 :

The coming page is the Summary information for your setting. Please remember your Wi-Fi Name and Password, then click Done.

() ito	otolink.net/phon	e/login.hti 1		
< Summary				
	Connection type			
	Wireless 2.4GHz			
	Network name(SSID)	TOTOLINK_N200RE		

STEP-9:

It takes several seconds to save the settings and then your router will restart automatically. This time your Phone will be disconnected from the router. Please back to the WLAN list of your phone to choose the new Wi-Fi name and input the correct password. Now, you could enjoy the Wi-Fi.



Bac	sk	Done
	•••••	

STEP-10 :

More features: Click Application.



STEP-10 :

More features: Click Application.



Method Two: login via PC

STEP-1:

Connect your computer to the router by cable or wireless. Then run any Web browser and enter http://itotolink.net in the address bar.

STEP-2:

Enter admin for the password and then click LOGIN.



